

Universal Nerf Bars
Fits EZGO TXT, CC DS, YAM G2-22
Installation Instructions
Black- Part# 6281
Gunmetal- Part# 6282
Stainless- Part# 6283-S



ASSEMBLY INSTRUCTIONS



*Always wear appropriate
eye protection!*

1. Remove the rubber or plastic rocker panel covers.
2. Hold the nerf bar in place on the frame at the desired location. Using a marker draw a line from the edge of the mount to the outside of the frame. (On Club Car gas carts start with the driver's side because you have to adjust for the air box.)
3. Turn the nerf bar around and line the mount up with the line that was drawn. This will be your guide for drilling the frame.
4. Mark the holes on the frame for drilling.
5. Using a 3/8" bit, drill the two holes in the frame.
6. Mount the nerf bar using the 2 stainless steel bolts and locknuts.
7. Repeat steps 1-6 for the other side of the cart.
8. Put the rubber or plastic rocker panel covers back on.
9. There is a 30" piece of anti-slip tape provided. You can cut this piece to your preference and apply to both nerf bars.

