

Xtreme Mats PRO Series Rear Mats

Instructions

Tools: Installation Pins & Drill Bit (INCLUDED)

Application:

1. Position the mat on your rear foot rest where it will be installed
2. Mark the location of the installation pin holes (You will be drilling out these holes)
3. Remove the mat and drill holes for the installation pins with the included drill bit
4. Reposition the mat and push the installation pins through the holes from the top to secure the mat to your rear foot rest

*The pins hold the mat in place because the fins of the pin will expand once installed so avoid pressing center of pins before installation

Enjoy your new mat!